

## Formaldehyde emission from wood based panels according to the Japanese desiccator method

JIS A 1460 / JANS 16 / ISO 12460-4



<b>Equivalent methods</b>	ISO 12460-4, JANS 16
<b>Desiccators</b>	(11 ± 2) L, glass
<b>Loading factor</b>	1800 cm <sup>2</sup> exposed area
<b>Sample specimen size</b>	(150 x 50) mm 5 – 12 test pieces depending on sample thickness
<b>Edge sealing</b>	No edge sealing
<b>Temperature</b>	(20.0 ± 0.5) °C
<b>Conditioning</b>	(20±2) °C / (65±5) %RH for 7 days
<b>Test duration</b>	24 hours ± 10 min
<b>Limit of quantification</b>	0.05 mg/L